

HOW TO CLEAN A FINGER VEIN SCANNER

Cleaning with Alcohol

- NO Hypochlorous acid aqueous solution
- NO Methanol (Methyl alcohol) CH₃OH
- NO Undiluted solution of Ethanol (Ethyl alcohol) C₂H₅OH

OK: Diluted Ethanol

Concentration: 70% - 83%

- You can use Shop-bought wet wipes for sterilization or rubbing ethanol which are not harmful for human body.

How to Clean the Scanner

Wipe an H-1 device with a soft cloth soaked with **diluted ethanol** along with the directions outlined 1-5.

- You can alternatively use a soft cloth soaked with neutral detergent.
- After you have completed steps 1-5, wipe dry with a soft cloth.
- In addition to cleaning the H-1, it's also important to clean users' fingers and hands, and keyboard/touch panel of the PC/tablet, etc.



1 Cleaning a finger rest in front

- Wipe the area highlighted



2 Cleaning a finger rest in the back

- Wipe the area highlighted



3 Cleaning a filter (glass)

- Wipe the area highlighted
- If you cannot remove a dust on the filter, remove the front finger rest and wipe the filter again



4 Cleaning inside the device (glass)

- Wipe the area highlighted



5 Cleaning outside the device

- Wipe the entire device



How to remove a front finger rest

- Press the finger rest from both sides
- Remove the finger rest upwards
- YOU CANNOT remove a back inger rest

